



# SÓLAS

## One-Touch Remote Quick Start Guide



## Turn Fire ON

Press  until you hear beeping and  appears. Takes about 20 seconds. Pilot and flames go to high.

## Adjust Flames

Press  or .


## High or Low Flame

Double-click  or .

**HI** or **LO** appears.




Flame goes to high flame first before going to low flame.

## Pilot Only

Press  until you see the fireplace pilot flame only.

## Turn Fire OFF

Press  until OFF flashes.





### TIP







If you recently turned the pilot off, give your fireplace a few minutes before starting up again.





## Choose Time & Temperature





To switch between °C and °F, press   together until mode changes.

## Set Time

1. Press   together until **-day-** appears.  
Press  or  to select the day of the week:


1 = Mon	2 = Tues	3 = Wed	4 = Thur
5 = Fri	6 = Sat	7 = Sun	

2. Press   together until **hour** flashes.  
Press  or  to select hour.


3. Press   together until **minutes** flash.  
Press  or  to select minutes.

4. To finish, press   together.

## TIME/TEMP MODE



## TIME MODE



### TIP




°F = 12-hour clock  
°C = 24-hour clock

## Set Thermostat



The remote's thermostat automatically adjusts the fire to maintain the thermostat temperature you set.

1. Press until appears and temperature flashes.
2. Press or to adjust.
3. Press to complete.



## Turn ON/OFF

Click to switch thermostat on or off.






### TIP



Your remote works like a thermostat. Keep it an ideal distance from the fireplace: 3–15 feet from the fireplace and other heat sources, including the sun. Use the Remote wall mount holder provided.

To create a preset schedule, see **Program Mode** in your Homeowner's manual.

## Comfort Blower (if equipped)


1. Press  until  flashes.
2. Press  or  to adjust blower.
3. To turn off the blower, click  until all four speed level bars disappear.






### TIP

The fan will stop 10 minutes after the fire is off or at pilot.

## Child Safety Lock

This safety setting locks all commands, except the  button.

### Turn ON/OFF

Press   together until  appears or disappears.

### 3–Hour Turndown

If your fireplace and remote are inactive for three hours—for example, if the remote is another room—your fireplace automatically turns down to pilot.

*Benefit*

*This will help save fuel and is an environmental benefit. Program the temperature and timer modes to maximize your heating efficiency.*

### 7–Day Pilot Shutdown

If there is no activity for seven days, the SÓLAS fireplace automatically shuts down the pilot.

*Benefit*

*The 7 day pilot shutdown is ideal if you happen to be away from home for an extended period of time or don't need the heat during warmer Spring and Summer months— you could save up to 5 months of unnecessary pilot consumption per year.*

## Remote Batteries

Your remote display indicates when the battery is low .

The remote uses a (2) AAA alkaline batteries—we recommend a name brand such as Duracell or Energizer.

The batteries should last **one full season**, depending on usage.

Remove the batteries in the off-season to extend battery life.

*For the Control Module batteries see following page.*



SÓLAS One-Touch Remote  
Battery Holder

## Control Module Batteries

Inside your fireplace, there are (4) batteries installed in the Control Module.

Frequent beeps for 3 seconds when the motor turns indicates the batteries inside the Control Module are low. Replace with (4) AA alkaline batteries.

1. Remove the Battery access plate on the Control Module.
2. Replace the batteries with (4) AA alkaline batteries (Duracell or Energizer) orienting them as indicated inside the holder.
3. Put cover back in place.



SÓLAS One-Touch  
Control Module – Battery Holder/Cover



***Congratulations on your purchase  
of a SÓLAS Fireplace!***

*We welcome you to the SÓLAS family of gas  
fireplaces. Each of our products are skillfully  
designed and expertly manufactured in the USA.  
We take great pride in every fireplace we make,  
with every product being fully tested throughout  
the production process to ensure your safety  
and warmth throughout the years.*

*Sincerely,  
The SÓLAS Team*



SÓLAS is here to help if you have any trouble with your SÓLAS Fireplace or SÓLAS One-Touch Remote. Please contact your local Dealer for support or contact SÓLAS directly at **[solasfires.com/contact](https://solasfires.com/contact)**.